

**KARO-10**  
**KARO-12**  
**KARO-40, -41**

## Operating instructions

Function	Setting	+ button	- button	Feedback
On/Off	on	tap		
	off		tap	
Dimming	up	touch and hold		
	down		touch and hold	
Ambient light sensor	deactivate	touch and hold*	tap 4 times	and switches off
	activate		tap 4 times	and switches on
Motion sensor	deactivate		tap 5 times	light flashes twice... and switches off
	activate		tap 5 times	and switches on
Restore default		tap 7 times	and switches on	

\* Multisens version only. The luminaire must be switched **on** prior to changing these settings.