

**KARO-30 Multisens**

**Operating instructions**

Function	Setting	Integrated switch	Feedback
On/Off	on	press quickly	
	off	press quickly	
Dimming	up	hold down	
	down	hold down	
Programming mode		hold down 7 seconds	light dims down
Ambient light sensor	deactivate	press quickly 4 times	and switches off
	activate	press quickly 4 times	and switches on
Motion sensor	deactivate	press quickly 5 times	light flashes twice... and switches off
	activate	press quickly 5 times	and switches on
Restore default		press quickly 7 times	and switches on